

CUSCO COILOVER KIT

CAR	MODEL	TYPE	STANDARD KIT PARTS No.	PILLOW BALL U/M TYPE PARTS No.	F	U/M	REPAIR SHOCK ABSORBER	SPRING ID/FH SPRING SELECTON	FRONT Adjustable height range	REAR Adjustable height range
-----	-------	------	------------------------	--------------------------------	---	-----	-----------------------	------------------------------	-------------------------------	------------------------------

U/M=UPPER MOUNT, P-AJ=ADJUSTABLE PILLOW BALL UPPER MOUNT, P-RG=NONADJUSTABLE PILLOW BALL UPPER MOUNT, A-RG=ALUMINUM RIGID MOUNT UPPER MOUNT

MITSUBISHI

MIRAGE	CJ4A	ZERO-2R	550 60R CN	550 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R02A	6k 73 / 200 [5/7/8/9]	- 70 - - 30	- 65 - 0	
					R	A-RG	5 stage adjustment 00B 60S W05A	4k 65 / 200 [3.5/5/6/7]			
		ZERO-2	550 60L CN	550 60L CP	F	P-AJ	5 stage adjustment 00B 60S S02A	6k 65 / 200 [5/7/8/9]	- 80 - - 5	- 65 - 0	
					R	A-RG	5 stage adjustment 00B 60S W05A	4k 65 / 200 [3.5/5/6/7]			
	ZERO-1	550 60E CN	550 60E CP	F	P-AJ	5 stage adjustment 00B 60S S02T	6k 65 / 200 [5/7/8/9]	- 80 - - 5	- 65 - 0		
				R	A-RG	5 stage adjustment 00B 60S W05T	4k 65 / 200 [3.5/5/6/7]				
	Comp-S	550 600 A		F	P-AJ	5 stage adjustment 00B 618 K08	6k 65 / 200 [5/7/8]	- 75 - - 45	- 70 - - 20		
				R	A-RG	5 stage adjustment 550 619 HS	4k 65 / 250 [3.5/5/6]				
	CA4A	ZERO-2R	515 60R CN	515 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R02A	6k 73 / 200 [5/7/8/9]	- 70 - 0	- 60 - 0	
					R	A-RG	5 stage adjustment 00B 60S W05A	4k 65 / 200 [3.5/5/6/7]			
			ZERO-2	515 60L CN	515 60L CP	F	P-AJ	5 stage adjustment 00B 60S S02A	6k 65 / 200 [5/7/8/9]	- 80 - 0	- 60 - 0
						R	A-RG	5 stage adjustment 00B 60S W05A	4k 65 / 200 [3.5/5/6/7]		
ZERO-1		515 60E CN	515 60E CP	F	P-AJ	5 stage adjustment 00B 60S S02T	6k 65 / 200 [5/7/8/9]	- 80 - 0	- 60 - 0		
				R	A-RG	5 stage adjustment 00B 60S W05T	4k 65 / 200 [3.5/5/6/7]				
Comp-S		515 600 A		F	P-AJ	5 stage adjustment 00B 618 K08	6k 65 / 200 [5/7/8]	- 65 - - 40	- 65 - - 15		
				R	A-RG	5 stage adjustment 550 619 HS	4k 65 / 250 [3.5/5/6]				
LANCER EVO.		CT9A EVO.	ZERO-2R	564 60R CN	564 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R01A	7k 73 / 200 [6/8/9/10]	- 65 - 0	- 65 - 0
						R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]		
			ZERO-2	564 60L CN	564 60L CP	F	P-AJ	5 stage adjustment 00B 60S S01A	7k 65 / 200 [6/8/9/10]	- 80 - 0	- 70 - 0
						R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]		
	ZERO-1	564 60E CN	564 60E CP	F	P-AJ	5 stage adjustment 00B 60S S01T	7k 65 / 200 [6/8/9/10]	- 80 - 0	- 70 - 0		
				R	A-RG	5 stage adjustment 00B 60S W04T	5k 65 / 200 [4/6/7]				
	CT9A EVO.	ZERO-2R	564 60R CN	564 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R01A	7k 73 / 200 [6/8/9/10]	- 65 - 0	- 65 - 0	
					R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]			
		ZERO-2	564 60L CN	564 60L CP	F	P-AJ	5 stage adjustment 00B 60S S01A	7k 65 / 200 [6/8/9/10]	- 80 - - 5	- 65 - 0	
					R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]			
	ZERO-1	564 60E CN	564 60E CP	F	P-AJ	5 stage adjustment 00B 60S S01T	7k 65 / 200 [6/8/9/10]	- 80 - - 5	- 65 - 0		
				R	A-RG	5 stage adjustment 00B 60S W04T	5k 65 / 200 [4/6/7]				
CP9A	ZERO-2R	561 60R CN	561 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R01A	7k 73 / 200 [6/8/9]	- 60 - 0	- 75 - 0		
				R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]				
	ZERO-2	561 60L CN	561 60L CP	F	P-AJ	5 stage adjustment 00B 60S S01A	7k 65 / 200 [6/8/9]	- 75 - - 10	- 70 - 0		
				R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]				
	ZERO-1	561 60E CN	561 60E CP	F	P-AJ	5 stage adjustment 00B 60S S01T	7k 65 / 200 [6/8/9]	- 75 - - 10	- 70 - 0		
				R	A-RG	5 stage adjustment 00B 60S W04T	5k 65 / 200 [4/6/7]				
CN9A	ZERO-2R	560 60R CN	560 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R01A	7k 73 / 200 [6/8/9]	- 60 - 0	- 75 - 0		

					R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]			
		ZERO-2	560 60L CN	560 60L CP	F	P-AJ	5 stage adjustment 00B 60S S01A	7k 65 / 200 [6/8/9]	- 75 ~ - 10	- 70 ~ 0	
					R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]			
		ZERO-1	560 60E CN	560 60E CP	F	P-AJ	00B 60S S01T	7k 65 / 200 [6/8/9]	- 75 ~ - 10	- 70 ~ 0	
					R	A-RG	00B 60S W04T	5k 65 / 200 [4/6/7]			
	CD/CE9A	ZERO-2R	510 60R CN	510 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R01A	7k 73 / 200 [6/8/9]	- 100 ~ - 50	- 90 ~ - 40	
					R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]			
			ZERO-2	510 60L CN	510 60L CP	F	P-AJ	5 stage adjustment 00B 60S S01A	7k 65 / 200 [6/8/9]	- 110 ~ - 55	- 80 ~ - 40
						R	A-RG	5 stage adjustment 00B 60S W04A	5k 65 / 200 [4/6/7]		
			ZERO-1	510 60E CN	510 60E CP	F	P-AJ	5 stage adjustment 00B 60S S01T	7k 65 / 200 [6/8/9]	- 110 ~ - 55	- 80 ~ - 40
						R	A-RG	00B 60S W04T	5k 65 / 200 [4/6/7]		
		Comp-S	510 600 A		F	P-AJ	00B 618 K09	6k 65 / 200 [7/8]	- 100 ~ - 75	- 60 ~ - 20	
					R	A-RG	510 619 HS	5k 65 / 250 [4/6]			
LANCER GSR	CM5A	ZERO-2	567 60L CN	567 60L CP	F	P-AJ	5 stage adjustment 00B 60S S01A	7k 65 / 200 [6/8/9]	- 110 ~ - 55	- 80 ~ - 40	
					R	A-RG	5 stage adjustment 00B 60S W04A	4k 65 / 200 [5/6]			
		ZERO-1	567 60E CN	567 60E CP	F	P-AJ	00B 60S S01T	7k 65 / 200 [6/8/9]	- 110 ~ - 55	- 80 ~ - 40	
					R	A-RG	00B 60S W04T	4k 65 / 200 [5/6]			
		Comp-S	567 600 A		F	P-AJ	00B 618 K09	6k 65 / 200 [7/8]	- 100 ~ - 75	- 65 ~ - 35	
					R	A-RG	510 619 HS	4k 65 / 250 [5/6]			
FTO	DE3A	ZERO-2R	540 60R CN	540 60R CP	F	P-AJ	Inverted 5 stage adjustment 00B 60S R02A	7k 73 / 200 [6/8/9]	- 80 ~ - 50	- 50 ~ 0	
					R	A-RG	5 stage adjustment 00B 60S W05A	4k 65 / 200 [5/6/7]			
		ZERO-2	540 60L CN	540 60L CP	F	P-AJ	5 stage adjustment 00B 60S S02A	7k 65 / 200 [6/8/9]	- 90 ~ - 10	- 50 ~ 0	
					R	A-RG	5 stage adjustment 00B 60S W05A	4k 65 / 200 [5/6/7]			
		ZERO-1	540 60E CN	540 60E CP	F	P-AJ	00B 60S S02T	7k 65 / 200 [6/8/9]	- 90 ~ - 10	- 50 ~ 0	
					R	A-RG	00B 60S W05T	4k 65 / 200 [5/6/7]			
		Comp-S	540 600 A		F	P-AJ	00B 618 K08	7k 65 / 200 [6/8/9]	- 85 ~ - 55	- 55 ~ 0	
					R	A-RG	550 619 HS	4k 65 / 250 [3.5/5/6]			
GALANT VR-4	EC5A	ZERO-2	532 60L CN	532 60L CP	F	A-RG	5 stage adjustment 00B 60S W01A	12k 65 / 200 [10/14/16]	- 65 ~ 0	- 60 ~ 0	
					R	A-RG	5 stage adjustment 00B 60S W05A	6k 65 / 200 [5/7/8]			
		ZERO-1	532 60E CN	532 60E CP	F	A-RG	00B 60S W01T	12k 65 / 200 [10/14/16]	- 65 ~ 0	- 60 ~ 0	
					R	A-RG	00B 60S W05T	6k 65 / 200 [5/7/8]			